

Installing differential, bevel gear and other parts (exchange)

Below instructions are extra important to check since each one individually can cause a gearbox failure that is not covered by warranty. **NOTE!** The instructions should be seen as a complementary reminder in addition to the car manufacturer's instructions.

- Use **oil** recommended by the car manufacturer or Hellsten Gears AB when filling/ leveling.
- Check the **oil level** before and after the test run, with engine idle and at the correct temperature.
- Check that there is **no leak** after test run.

Volvo differentials

- **NOTE!** Two different types of oil are added; a Haldex oil and a GL oil for the differential.
- Please see separate instructions from Hellsten Gears AB.

**WARRANTY ONLY APPLIES IF THESE INSTRUCTIONS HAVE BEEN FOLLOWED.
CONTACT TECHNICAL SUPPORT IF ANYTHING IS UNCLEAR.**